

LED Emergency Tri-proof Batten Light | 24W











Shenzhen ERS Technology

Factory Add: C209, Baohuasen International Center, Glanjin Second
Road, Xixiang Town, Bao'an District, Shenzhen, China
Warehouse Add: 57 Tarnard Dr., Braeside VIC 3195

Tel: 048 470 3010

















APPLICATION

Indoor and outdoor lighting, with IP65, it can be used at chick en farm, basement, car pariking, warehouses, corridors, outside of building, etc



SPECIFICATIONS

Item No.	ERS-TRI24WE		
Product Size (mm)	1207X91X78		
Power	24W		
LCP	22.8W		
Emergency Power And Time	4W 120min		
Input Voltage	AC220-240V,50Hz		
Opal Diffuser Material	PC		
Body Mateial	PC		
Body Colour	Grey		
Clips	stainless steel clips		
Driver Brand	PHILIPS Element non—isolated driver 3 years warranty		
Efficiency	150lm/w		
LED Type	SMD 2835		
ССТ	3000K,4000K,5000K,6500K		
CRI	Ra > 80		
Power Factor	> 0.9		
Beam Angle	120°		
IP Rating	IP65		
Warranty	3 years		
VEET	Approved		
IPART	Approved		

Shenzhen ERS Technology

Factory Add: C209, Baohuasen International Center, Qianjin Second Road, Xixiang Town, Bao'an District, Shenzhen, China Warehouse Add: 57 Tarnard Dr, Braeside VIC 3195

Tel: 048 470 3010



















LED MANUAL INSTRUCTION



- Installation should be done by registered electricians.
- Before replacing the driver, please switch off the power supply and wait until it cools down completely.
- 3 Never touch the working luminaire
- In any case of malfunction, switch off the power supply immediately, and do not try to repair it yourself.
- **5** Repairment should only be done by registered electricians or official service agent.





Model	Power	Fixing Hole Centre
ERS-TRI12WE	12W	280mm
ERS-TRI24WE	24W	770mm
ERS-TRI36WE	36W	770mm






Switch off the power supply before installation







3. Fix the luminaire with the brackets




2.According to the Fixing hole centre, instal expansion bolts and screws, instal the bracket.




4. Finish installation










2. Take out of the diffuser







5.Insert the cable through the cable gland



6.Connect the wires,L to L , N to N, = to =

Shenzhen ERS Technology

Factory Add: C209, Baohuasen International Center, Qianjin Second Road, Xixiang Town, Bao'an District, Shenzhen, China Warehouse Add: 57 Tarnard Dr, Braeside VIC 3195

Tel: 048 470 3010



























7. Put back the LED module


8. Close the luminaire

9. Buckle the clips










PACKING

N.W.(KG)	G.W.(KG)	CARTON SIZE(mm)	QTN/CTN
15	17	1225X290X260	9



Shenzhen ERS Technology Factory Add: C209, Boohuosen International Center, Qianjin Second

Road, Xixiang Town, Bao'an District, Shenzhen, China

Warehouse Add: 57 Tarnard Dr, Braeside VIC 3195

Tel: 048 470 3010













