LED Ceiling Light
INSTRUCTION MANUAL

Built−in sensor

∅255mm

60

∅299.58mm

60

∅380mm

63

SAA APPROVALS

Victorian Energy Upgrades

3 year warranty

IPART
Independent Pricing and Regulatory Tribunal
New South Wales

LM-80 TM 21 LM 79
ISTMT LCP

ESSENTIAL SERVICES COMMISSION

Accessories

× 1   × 1   × 1   × 4   × 4

1.	2.	3.
	L L	X
	N N	Y

X	Y
60mm	41mm

LED Ceiling Light Installation Guide:

1. Switch off the power supply before installation；
2. Remove the mounting base, insert the cable throgh the cable gland; Connect the wires, L to L, N to N;
3. Punch holes at the installation positions (X, Y) with tools ;

SAA APPROVALS

Victorian Energy Upgrades

3 year warranty

IPART
Independent Pricing and Regulatory Tribunal
New South Wales

LM-80 TM 21 LM 79
ISTMT LCP

ESSENTIAL SERVICES COMMISSION

4. Insert the expansion plug into the drilled hole and fix the installation base on the wall with screws;

5. Open the groove baffle on ceiling lamp back, instert the ceiling lamp groove to installation base, and make sure the lamp is installed & fixed to installation base, then close the baffle;

6. Switch on the power supply after installation.

Light

SAA APPROVALS

Victorian Energy Upgrades

3 year warranty

IPART
Independent Pricing and Regulatory Tribunal
New South Wales

LM-80 TM 21 LM 79
ISTMT LCP

ESSENTIAL SERVICES COMMISSION