

LED Canopy Light A

Accessories



Factory setting of sensor: When turn on the lamp, sensor function is closed; If you need to open the sensor, please use our remote controller as below.

Show Case:

1. Press “ON” to open sensor function, default setting: daylight (OFF), hold time (2 seconds), standby brightness 0%;
2. Set the data you need.

For instance, you need the lamp holds on 2 mins after you leaving site and then dimming to half brightness, just press the “2 min” in Hold Time section, and press “50%” in Standby brightness section.

If need to change daylight sensor data, for instance, you want the lamp turns on when the brightness is < 300, just press “300 Lux” in on Lux section (Light Threshold); “Disable” is to close daylight sensor function.

If want to close the sensor function, just press “OFF”.

D: Press one time, Daylight Sensor working only.

On: Press one time, work with default setting.

Sc1: Hold on 30 minutes and then dimming down to its 50% luminosity. Daylight Sensor OFF.

Sc2: Hold on 10 minutes and then dimming down to its 20% luminosity. Daylight Sensor OFF.

M: Press one time, Motion Sensor working only.

Record the current environment lux.

Sc3: Hold on 30 seconds and then turn OFF. Daylight Sensor OFF.

Technical Parameter

Input Voltage	AC220-240V,50Hz	LED Chips	Lumileds 3030
Beam Angle	120°	Sensor	Daylight & Microwave Motion Sensor
Driver	Sosen/Meanwell	Power Factor	0.95
CCT	2700-6500K	CRI	Ra 80
Working Temp	-20 ~+50	IP Rating	IP65

Installation

⚠ WARNING

1. Switch off the power supply before installation.

OFF

2. Fix the installation bracket to ceiling.

3. The bracket installation finished.

4. Fix the canopy to bracket.

5. The canopy installation finished.

ON

⚠ WARNING

6. Switch on the power supply after installation.

Reminder

- We appreciate your choice!
- Please read the instruction manual before installation and keep it well.

⚠ Warning

- To avoid the accident of damage, falling, electric shock or fire, please do not reform the lamp or replace the accessories and confirm with us if you need to change the mounting method.
- Please authorize the installation to qualified installation personnel and obey to the instruction manual. Any unsuitable installation will easily cause the accident of falling, electric shock and fire etc.
- Please cut off the power before installation or any maintenance of the lamp.
- Please cut off the power when it smokes or smells awfully since the accident of fire or electric shock may incur. Ask the qualified personnel for maintenance.
- Please do not dismantle the lamp by yourself since the accident may incur.
- Please do not touch the driver when the lamp works.

Application

Suitable for food processing and parking areas, service station canopies, car park, retail areas, shopping malls and manufacturing facilities.

Troubleshooting&Solutions

Malfunction	Troubleshooting	Solutions
Not working	1. Check whether the power line is properly connected.	1. Reconnect the power wire.
	2. Check whether the power plug is loosen.	2. Re-plug the loosen power plug.
	3. Driving power supply failure.	3. Call the after-sales phone to confirm the problem and replace the normal product.
	4. LED chip breakdown.	4. Call the after-sales phone to confirm the problem and replace the normal product.
	5. Daylight function is turned on.	5. Check the remote control instructions and reset.
LED dim or flashing	1. How to use the remote control to set the brightness.	1. Check the remote control instructions and reset.
	2. The sensing function turned on, and the test function turned on.	2. Check the remote control instructions and reset.
	3. The output of the driver is abnormal.	3. Call the after-sales phone to confirm the problem and replace the normal product.
	4. LED chip breakdown.	4. Call the after-sales phone to confirm the problem and replace the normal product.

Warranty

- Five years warranty.
- During the warranty period, the client shall return the failed parts by courier for inspection and repair. After inspection and repair, the supplier shall send the fixed parts or new parts back. Each party shall bear the freight cost accordingly.
- Keep the warranty card as the warranty certificate.
- The following conditions are not covered by the warranty, and the supplier provides maintenance services by charging maintenance fee:
 - (1) All artificial damages, including damages from operation, usage, storage nonconformity with the instruction manual, abnormal working condition etc;
 - (2) Dismantling, maintenance, modification or unqualified repairing for the products without the supplier's authorization;
 - (3) No warranty cards and documents;
 - (4) Damages caused by user's improper delivery or due to force majeure (including fire, flood, thunder hit, earthquake etc).
- All rights reserved.

Warranty Card

Name		Type	
Number		Date	
User		Tel./E-mail	

Date	Issue	Note

Item List

1.Lamp body	— pcs	<input type="checkbox"/>
2.90 degree aluminum reflector	— pcs	<input type="checkbox"/>
3.120 degree aluminum reflector	— pcs	<input type="checkbox"/>
4.Transparent reflector	— pcs	<input type="checkbox"/>
5.Transparent reflector connecting plate and screws	— pcs	<input type="checkbox"/>
6.Aluminum reflector connecting plate,snap ring and screws	— pcs	<input type="checkbox"/>
7.Rubber ring	— pcs	<input type="checkbox"/>
8.The reflector seaing gasket	— pcs	<input type="checkbox"/>
9.Transparent reflector organic glass plate,snap ring	— pcs	<input type="checkbox"/>
10.Accessory Screws	— pcs	<input type="checkbox"/>
11.Instruction Manual (including Warranty Card and Item List)	— pcs	<input checked="" type="checkbox"/>
12.Qualification Certificate	— pcs	<input checked="" type="checkbox"/>

ERS tech

LED Canopy Light Instruction Manual

